

D-Step<sup>™</sup> Mats remove up to 98+% of contaminants from the bottom of shoes and wheels

MKT2-S

3102ES-001



Depending on the amount of traffic, clean the mat when it becomes soiled. It should be thoroughly cleaned at least once per day.

	Mat Cleaning Supplies	
MKT3	MKT2-S B C	<ul> <li>Cleaning Pads (4)</li> <li>Cleaning Pad Holder (1)</li> <li>18" Rubber Squeegee (1)</li> <li>Extension Handles (2)</li> </ul>
D	N ALCTO	<ul> <li>Extension Handles (2)</li> <li>Combination Scrubber &amp; 10" Squeegee (1)</li> </ul>
E	3102ES-001 or 330PD-001 F	D-Lead®All Purpose Cleaner (1 gal) D-Lead®Surface Cleaner (1 gal)

STEP 1: Dilute D-Lead® All Purpose Cleaner 1:10 with water or Dilute D-Lead® Surface Cleaner 1:4 with water.

330PD-001

**STEP 2:** Apply diluted cleaner sparingly to mat.

**STEP 3:** Using mat cleaning scrub pads or combination scrubber and squeegee, scrub using short firm strokes.

**STEP 4:** Remove liquid with rubber squeegee.

**STEP 5:** Use wet mop, towel or wet vacuum to recover cleaner around edge of mat.

**STEP 6:** If mat is heavily contaminated repeat steps 1 through 5.

**STEP 7:** After every fourth cleaning, rinse mat with warm water and squeegee dry. Use wet mop, towel or wet vacuum to recover water around edge of mat.

#### Warning: Mats are slippery when wet!

www.esca-tech.com



3747 N. Booth Street Phone: (414) 962-5323 Milwaukee, WI 53212 USA Fax: (414) 962-7003







# INSTALLATION

#### Mat Preparation

Before unrolling mat, allow mat to reach room temperature. Unroll and place on smooth surface to allow mat to relax for a minimum of 24 hours.

# Location

Select a smooth, level surface between the dirty area and the clean area you wish to protect. Place the mat where foot and wheel traffic will cross the mat.

# Surface Preparation

After selecting a smooth level flat location for installation, thoroughly clean the surface of the existing floor. Sweep away loose dirt, mop and let fully dry. If wax is present on the floor, then completely strip wax from floor where mat is to be applied.

#### Installation

Remove liner covering the adhesive strips and apply the mat to the flat surface face down. Peel off the surface liner slowly. With two people lift and flip mat. Starting at one edge and working to the opposite edge, slowly apply mat to the floor. Immediately after mat has been applied to floor; clean mat (see reverse side for instructions). Mat is now ready to use.

It is strongly recommended to apply a bead of silicone caulk around the perimeter of the mat after installed to prevent water from seeping and collecting under the mat when cleaning. If water accumulates under the mat, mold can develop between the mat and the floor.

# Forktrucks

Do not turn forklift truck wheels while on the mat. This will cause mat to tear.

# Cleaning

Clean the D-Step<sup>™</sup> Permanent Tacky Mat with D-Lead<sup>®</sup> All Purpose Cleaner or D-Lead<sup>®</sup> Surface Cleaner. <u>Do not</u> clean with solvents, acids, alkaline, bleach or adhesives.

# Disposal

D-Step<sup>™</sup> Mats are made of recyclable materials.

# To Repair Tear

If mat should tear from abnormal use, it can be repaired with Simple Fix Indoor Glue Pen.

www.esca-tech.com

# To Repair Edging

If edging becomes separated from the mat, clean edges then glue with Simple Fix Indoor Glue Pen.



3747 N. Booth Street

Phone: (414) 962-5323

Fax: (414) 962-7003

Milwaukee, WI 53212 USA

© 2018 ESCA Tech, Inc.